EL-WiFi-DTP+

Dual Channel External Thermistor WiFi Temperature Sensor



- Measures temperature range -40°C to +125°C (-40°F to +257°F)
- Dual channel recording through two external thermistor probes
- Wirelessly stream and view data on the EasyLog Cloud, App or on a PC
- Sensor set up is easy using free PC software
- · View and analyse multiple sensors, including graphing of historic data
- · Configurable high and low alarms with indicator
- · Sensor memory stores data even if WiFi is temporarily disconnected

The EL-WiFi-DTP+ measures the temperature of the environment in which the two probes are situated. The probes are connected to the sensor via a 160mm of the sensor via a 160m

a given wireless network, either connect WiFi software on the network, or yLog Cloud app on a mobile phone with r can then be placed anywhere within r temporarily loses connectivity with the it is able to communicate again with the PC

application or EasyLog Cloud (max 30 days at 10 second sample interval).



The sensor is IEEE 802.11bgn* (2.4GHz) compliant, supports WEP, WPA/WPA2 encryption and enterprise networks (PEAP, TTLS, FAST).

The EL-WiFi-DTP+ has a protection rating of IP40 and the probes IP67. The unit is freestanding, but can be attached to a wall or surface using the bracket provided. The unit can be clipped in and out of the bracket as required.

SPECIFICATIONS

	Minimum	Typical	Maximum	Unit
Battery life		>6		Months
USB supply voltage (@500mA)	4.5	5.0	5.5	Vdc
Operating temperature range	-20 (-4)		+60 (+140)	°C (°F)
Logging period (user configurable)	10 sec	10 min	12 hrs	
Transmission period (user configurable)	1 min	1 hr	24 hrs	
Temperature measurement range	-40 (-40)		+125 (+257)	°C (°F)
Temperature measurement resolution		0.01 (0.02)		°C (°F)
Temperature display resolution		0.01		
Temperature accuracy		±0.2°C/±0.4°F (-15 to +80°C/ +5 to +176°F)	±0.6°C/±1.2°F (-40 to +125°C/ -40 to +257°F)	°C/°F
IP Rating	Logger IP40, Probe Tip IP67 (Bung fully inserted, not permanently powered, probe connectors (including Y Splitter) fitted and fully inserted, device mounted vertically.)			
Dimensions	82 x 70 x 32mm (3.22 x 2.75 x 1.26")**			

^{*} MAC Address starting 98:8B:AD:2...... only

^{**} Excluding probe and mounting bracket



ACCESSORIES

PSU-5VDC-USB-USA	USB mains power adapter for USA
PSU USB-UK	USB mains power adapter for UK
PSU USB-EU	USB mains power adapter for EU
EL-WiFi-Alert	Audible and visual alarm for EL-WiFi sensors
EL-P-TP+	Replacement high accuracy thermistor probe

INCLUDED IN THE B	OX
EL-WIFI WALL BRACKET	Wall mounting bracket for EL-WiFi sensors
2x EL-P-TP+	3m high accuracy thermistor probes
CABLE USB A-MICRO B	USB Type A to Micro B
EL-PROBE-Y-ADAPTOR-TP	160mm Y ADAPTOR

Authorised Distributor

DL TECHNOLOGY PTE LTD

EL-WiFi-DTP+

Dual Channel External Thermistor WiFi Temperature Sensor



EL-WiFi-WIN

Lascar's WiFi software* is available as a free download from: www.lascarelectronics.com/software/easylog-wifi. Easy to install and use, EL-WiFi-WIN allows easy connection of sensors to a WiFi network. The user can select where data is stored - the PC or the Cloud.



EasyLog Cloud

Your Data Anytima. Anywhere.

Facel or Cloud harpesses the power of IoT to automate data nabling you to monitor and evices in different locations neasily scales to meet your ems with just a few measuring the thousands of devices

You will need to create an account at www.easylogcloud.com before setting up your cloud-connected data logger.



Features at a glance*



Store your data logging records securely on the Cloud



Connect multiple users with variable account privileges



Connect data loggers from multiple sites in a single account



Easily access your most important data, anywhere



Remotely manage all of your data logging devices



Never miss a critical event with flexible advanced notifications



Review and analyse your data with powerful graphing functionality



data events and system activity with a detailed event log

*Features depend on account type.

Battery Life and Power Supply

The battery can be recharged (unit must be between 0 - 40°C) via a PC, a USB +5V wall adapter, or a portable USB battery pack using the USB lead provided. It can also be permanently powered by a USB wall adapter or USB battery pack. Readings may be affected while the internal battery is being charged. However, once charged, continued connection of the charger will have no effect.

Battery life is dependent on: transmission period, WiFi encryption method, WiFi encryption key rotation frequency (determined by the router/access point), signal strength between router/access point and WiFi device, presence volume and type of WiFi traffic from other devices, sample rate and operating temperature.

Specifications liable to change without prior warning

*Requires Windows 7, 8.1, 10

Tel: +65 6592 5006 Email: info@dl-tec.com Web: www.dl-tec.com